# Intesis<sup>®</sup>

This document describes how to link the Intesis AC Cloud Control device (hereafter referred to as "AC Cloud Control") to the Wi-Fi network without being logged in, via Bluetooth using the Automatic mode. For other configuration modes, please refer to the <u>Device Configuration with Bluetooth</u> manual.

This configuration guide applies to the AC Cloud Control with the order code INWFIXXX001**R1**XX. If you have a Brand Specific RC and the order code is different, please refer to the <u>Quick Wi-Fi Configuration</u> guide.

#### Note:

- To link the AC Cloud Control to the Wi-Fi, configure your Access point in the 2.4GHz band and the 802.11 b/g or /n mode.
- The AC Cloud Control generates its own network named INTESIS\_XXXXXX, being XXXXXX the last 6 digits of the AC Cloud Control MAC address.
- Memorize the name and password of the Wi-Fi network to which you want to link the AC Cloud Control.

### What is needed:



## Before starting the linking process with the App:

- 1. Install the AC Cloud Control following the corresponding Installation manual.
- 2. Keep your Smart device close to both the Access point and the AC Cloud Control.
- **3.** Turn on the Bluetooth of your Smart device.

## Once you completed the previous steps, open the AC Cloud Control App and proceed as follows:



